
WORK INSTRUCTION FOR SEMI AUTOMATIC GLUING MACHINE

WI-LPR-002-001

00

E REQUIREMENT oves ce Mask Ifety Shoes	Turn on the founter. Turn on the feeder switch on the left side for automatic feeding. In Charge Person: Folder	
NERAL SAFETY REQUIREMENT ake sure that the machine is ed off" before doing cleaning or tenance.	4.20 Adjust the pressing timer in the first glue and hotmelt point by rotating it to desired time delay: 0.75 seconds for EPSON items (standard), 3 seconds for CMBP items (to avoid congestion). In Charge Person: Folder	The second second
now the emergency stop button. sport any incident, accident, or near oserve proper hygiene during break	4.21 Set the set-counter according to the number of sets desired or required. Turn the buzzer on. It will alarm if there is a system error during gluing process. In Charge Person: Folder	
and after work. and the available maps so you d know what to do in case of an	4.22 Push the green button to start the running of conveyor system. In Charge Person: Folder	
ake sure to wear all prescribed while in production.	4.23 Conduct eight (8) pcs trial run before proceeding to	7
case of emergency, immediately the "emergency stop" button.	mass production and one (1) pc after refilling of white glue. The operator will check the alignment and application of the glue by lifting the glue tab to check the weak glue problem. Note: After the evaluation of QA, proceed to mass production.)//

WI to achieved number of ets desired to avoid disarranged pile of boards



	AFFENDAN		
FIRST NAME	LAST NAME	DIV. / DEPT.	SIGNATURE
1	- Willes	6201	·A:
JOVANIE	Espation	Proof	- Qu
Tanai	Dinesia	Pred	18
King Chager	Salesh	Ful	W.
ROY WALTER	WAGEN	FROD	2
Vashva	MANDO	PROD	-0
22-14-1	LABRITO	TROD	(2)
Jamari	Lagi	Front	- The
Rumel	Agurre	Pro	(Zip
		- 11	
			\bigcirc
	-		

Morning meeting regarding Damaged encountered on VP items

PCF-04-0008

-		